

SPECIFICATIONS

Capacity: 5kg

Division: 1g

Units: g/kg/lb:oz/water ml/milk ml/ water fl'oz/ milk fl'oz

Tare function

Auto power off

Low battery and overload indication

1XCR2032 battery

INSTRUCTION

Place the scale steadily on hard and flat surface. Clean table is best.

Press the "ON/TARE" button to switch on the scale and it will get ready for use when the LCD screen shows "0g" after full display.

Press the "UNIT" button and you can choose from the different units: g/kg/lb:oz/water ml/milk ml/ water fl'oz/ milk fl'oz.

Put the goods you want to weight on the platform of the scale and weight will be showed on the screen.

Press the "ON/TARE" button to clear the weight of the things on the platform and the screen will show "0g". Then put the food on the platform and the weight of the stuff you add will be displayed on the screen.

Continue to use the "ON/TARE" button and you can get respective weight of more things through repeating tare conveniently. And when all the stuff get remove off the platform, the total weight will be showed on the screen.

Press the "ON/TARE" button to switch off the scale when the screen shows "0g" if no more weighing is needed or it will auto off if no further using within seconds.

Please change a new battery when "LO" appears on the screen which indicates that the battery is out of power.

"O-Ld" shows on the screen indicates overload.

Attention:

Please put the scale on hard and flat surface (clean flat table is best) and make sure it is steady before use.

Please use soft tissue with alcohol or glass cleaner to clean the surface if it is dirty. No soap or other chemicals. Keep it away from water, corrosive liquid, heat and extreme coldness.

The scale is high precision measuring device. Never knock it heavily or try to disassemble it and please handle it carefully to avoid dropping or breaking during moving.