## SAVE THESE IMPORTANT SAFETY INSTRUCTIONS

Please read all instructions before using this appliance

These instructions are also available on our website. Please visit www.hot-europe.com



WARNING: Do not use this appliance near bathtubs, showers, basins or other vessels containing water.

WARNING: When the hairdryer is used in a bathroom, unplug it after use since the proximity to water presents a hazard even when the hairdrver is switched OFF.

For additional protection the installation of a residual current device (RCD) having a rated residual operating current not exceeding 30mA is advisable in the electrical circuit supplying the bathroom. Ask your installer for advice.

This appliance can be used by children aged from 8 years and above, and by persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved.

Children shall not play with the appliance.

Cleaning and user maintenance shall not be made by children without supervision.

If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.

WARNING: Do not leave the appliance unattended. Do not allow bare skin or the eyes to come into contact with any heated surface on the appliance when in use.

Do not place the appliance on any heat-sensitive surfaces when hot or plugged into the mains. Always unplug the appliance when not in use.

WARNING: Do not block the air inlet or outlet during use. When using the appliance, care must be taken to prevent hair entering the air inlet opening. The air outlet opening of this appliance will become hot during use, avoid touching the outlet or any accessories attached to the outlet.

**NOTE:** Use on towel dried hair only.

## WARNING: Should this product malfunction, do not attempt to repair it. This appliance has no user-serviceable parts or compohents.

#### **GUARANTEE AND SERVICE SECTION:**

Your Revlon appliance is guaranteed against defects under normal use for three years from the original date of purchase. If your product does not perform satisfactorily because of defects in materials or manufacture, within the warranty period, it will be replaced. Please retain your receipt or other proof of purchase for all claims within the warranty period. The guarantee becomes void if the proof of purchase is not presented. Simply take the appliance back to the retailer from where purchased. along with a valid till receipt, for exchange free of charge,

This guarantee does not cover defects which have occurred due to misuse, abuse, or are caused by failure to follow the instructions contained within this manual. This does not affect your consumer statutory rights. The manufacturing date is given by the 4 digit Batch Number marked on the rear of the product The first 2 digits represent the week of manufacture, and the last 2 digits represent the vear of manufacture. Example: 3419 - product manufactured week 34 of the year 2019.

For product support, please visit us at:

www.hot-europe.com/support

Or contact us by phone: +44 (0) 207 949 0115

For product information, visit us at:

www.revlonbeautvcare.com

This appliance complies with EU legislation 2012/19/EU on end of life recycling. Products showing the 'Crossed Through' wheeled bin symbol on either the rating

label, gift box or instructions must be recycled separately from household waste at

the end of their useful life.

Please DO NOT dispose of appliance in normal household waste. Your local appliance retailer may operate a 'take-back' scheme when you are ready to purchase a replacement product, alternatively contact your local government authority for further help and advice on where to take your appliance for recycling.

This product carries the CE mark and is manufactured in conformity with the Electromagnetic Directive 2014/30/EU, the Low Voltage Directive 2014/35/EU,

the ROHS Directive 2011/65/EU and the Energy and Using Products Directive 2009/125/EC.

220-240V ~ 50-60Hz 3 41-3 72A

Type#, EH5212DC

The REVLON® trademark is used under licence from Revion by Helen of Troy Limited.



European Headquarters Helen of Troy - Kaz Europe Sàr Place Chauderon 18 CH-1003 Lausanne -Switzerland

KAZ Hausgeräte GmbH Kölner Strasse 23 DE-57439 Attendorn - Germany

HOT (UK) Ltd PO Box 5984 Sheffield S2 9GN - United Kingdom

© 2020 Helen of Troy. All rights reserved. (AW013832)



**ONE-STEP** HAIR DRYER AND STYLER

11.00

**RVDR5212UK2** 



AW ISSUE No#: 1 Date: 04MAY20

## **OPERATING INSTRUCTIONS**

This appliance is intended for household use only. The appearance of this appliance may differ from the illustration. Only use this appliance for its intended purpose as described in this manual. Do not use attachments not recommended by the manufacturer.

#### **INNOVATIVE 2-IN-1 DESIGN**

This unique tool combines the drying power of a hairdryer and the smoothing effect of a paddle brush in one easy step. Combined with powerful airflow, the paddle brush design is perfect for smoothing out curls, waves, and kinks often found in the backside of the hair, resulting in soft, gorgeous styles.

#### OVERHEATING CUT-OFF

This appliance is equipped with a thermostat that will cycle OFF (0) should the heat of the dryer exceed the optimum drying level, due to partially blocked air inlet or outlet openings. In the event that the appliance stops, turn the appliance OFF (0) and allow it to cool down. Once the appliance cools, the thermostat will automatically reset and usage may resume.

#### IONIC® CONDITIONING

Helps to eliminate static and frizz and enhances shine for silky-smooth results.

#### STYLING

- Always towel-dry hair to remove excess water and smooth it with a comb or brush to untangle. Styling hair will be faster if it is slightly damp, not wet.
- Plug the appliance into an electrical outlet and adjust the switch to the selected setting. Use the HIGH setting (II) on thick or coarse hair and the LOW setting (I) on fine or thin hair.
- For best results, separate hair into manageable sections.
- Starting with the bottom section of hair, place brush dryer over the hair and close to the roots. Run brush toward the ends. To prevent over-drying, do not concentrate the airflow on any one area for an extended period of time.
- Repeat for the remaining sections until desired look is achieved.
- Turn the appliance off when styling is complete. Allow the unit to cool completely before storing.

**CLEANING** - Always unplug the appliance from the mains after use and allow it to cool before cleaning. Wipe the outer surface of the dryer with a slightly moist cloth, then wipe dry.

#### STORAGE - Always unplug when not in use.

Allow the appliance to cool before storing. Always store in a dry location. Do not pull or twist the cord. Do not wrap the cord around the appliance, as this may cause the cord to wear prematurely and break. Regularly check the power cord for wear and damage (particularly where it enters the appliance and the plug).

#### FEATURES

- A. AIR OUTLETS
- B. BRISTLES
- C. BRUSH AREA
- D. HANDLE
- E. 4-POSITION SWITCH
- F. AIR INLETS



# Helen | of Troy

Start Date	19FEB19
Model#	RVDR5212UK2
UK/E	UK
Agile AW#	AW013832
AW Issue#	No#: 1 Date 04MAY20
Languages	English
File Name	rvdrib.RVDR5212UK2.AW015231.INDD
Designer	Simon Finch (SYZ Design)
Factory	Dechang
Bar Code#	n/a

### **Packaging Specifications**

Dimensions	H184mm x W89mm
Material	80gsm Wood free paper
Finishes	Roll fold
Colours	Black

This proof is not intended for colour matching but for colour indication



## Helen | of Troy

## Proof Stages

19FEB19	1st proof for comments
26FEB19	Added AW# & HOT logo
27FEB19	Updated Guarantee section
28FEB19	Released for production
	No#: 1 Date 28FEB19
04MAY20	Updated AW# and released for production

## Approvals

BM/MKT	04MAY20	Camille Bosson
MKT MNG		
Design	04MAY20	Loc Pham
Eng. UK/E		
Legal		

### Helen of Troy - Kaz Europe Sàrl

Creative Department Place Chauderon 18 1003 Lausanne Switzerland