


*comfort*

## MANUAL INSTRUCTION

### 18INCH STAND FAN



**MODEL NO: COM-18BK**

Importer by :

**ROMICO J.T. TRADERS LTD**

**11 DIOS STR., 1058 NICOSIA-CYPRUS**

**P.O.BOX 24997-1306, NICOSIA CYPRUS**

**Made in P.R.C.**

*Read all Instructions before Using*

Warning: To reduce the risk of fire, electrical shock, and injury to person, the following must be adhered to:

1. This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
2. Children should be supervised to ensure that they do not play with the appliance.
3. The product is for household use only.
4. Connect the appliance to a single-phase AC supply voltage, specified on the rating plate.
5. Never leave the fan un-attended while it is in use. Always turn the fan to the "OFF" position, and unplug the fan from the electrical outlet socket, when not in use.
6. Extreme caution is necessary when any fan is used by or near children, invalids or elderly persons, and whenever the fan is left operating un-attended.
7. The fan cord must not be placed under carpets, or covered with throw rugs, runners or similar. Arrange the cord away from the traffic area, and where it will not be tripped over.
8. Do not operate the fan with a damaged cord or plug, or after the fan malfunctions, or has been dropped, or damaged in any manner.
9. If the supply cord is damaged, either the manufacturer, or the service agent, or a similarly qualified person, must replace it, to avoid a hazard.
10. Use the fan in a well ventilated area. While in use, ensure that the airtakes or exhaust openings are not blocked un-expectedly, and the fan

distance from the wall or corner must be no less than 20cm. The fan should not be placed below or besides any curtains or similar

11. To avoid mechanical danger when in use, do not insert, or allow fingers, or any other objects into the grill. Do not block the air-intakes or the exhaust openings in any manner.

12. The fan must only be placed, and used on a flat dry floor.

### Assembly Instructions

The fan is packaged with its grills un-attached. You must attach the grills before operating the fan.

**Warning:** Never operate the fan without its foundation and other parts. The fan must only operate in the up-right position, and any other position will be hazardous.

Do operate the fan only in upright position; any other position could create a hazardous situation.

Assemble the foundation and other parts of the appliance in the following sequence:

- a). Unpack the fan and remove all parts from the package
- b). Adjust the fan head to the up or down position, and then tighten the fasten screw.
- c). Use the fasten nut for the back grill to attach the back grill to the fan head, and then use the fasten nut for the fan leaf to hold the fan leaf in place.d). To attach the front grill to the back grill, you must use the grill ring carefully to hold them together, and fasten the grill ring with the screw provided.

### Operating Instructions

Before using the fan make sure that it is on a flat and stable surface.

Damage may occur if it is placed on an incline or decline.

1. Set all the switches to OFF position, and then insert the plug directly into a standard AC socket-outlet. Be sure plug fits tightly into outlet.
2. Gently touch the button "ON/SPEED" to start the fan and select your desired fan speed.
3. Set the time by gently touch the knob "TIMER" to select a desired timing level, the range is between 0-2 hours.
4. If you want to enlarge blast area in your room, pull the button"OSCILLATION" on the head cover and the grill will oscillate; blast your room in large scope. To stop oscillating, just push the button "OSCILLATION".
5. To completely shut the fan off, first touch the button"OFF" once, and then remove plug from the socket-outlet.

### Cleaning / Maintenance Instructions

To safely take care of your fan, please remember to follow these instructions below:

1. Always remove the plug from the socket-outlet, and allow the fan to stop completely before cleaning the fan.
2. Do not allow water to drip on, or enter into the fan housing.
3. Always use a soft cloth, moistened with a mild soap solution.
4. Do not use any of the following agents as a cleaner: Gasoline, Thinners, or Benzene.
5. In case of malfunction or doubt, do not try to repair the fan yourself, it may result in a fire hazard or electric shock.

**FAN Cleaning**

Clean the fan grill, housing and base with a soft damp cloth. Do not attempt to remove the fan blades. Please use caution around the motor housing area. Do not allow the motor, or other electrical components to be exposed to water.

**FAN Storage**

When storing your fan in the off-season, it is important to keep it in a safe dry location. It is important to protect the fan head from any dust. We strongly recommend using the original box, when storing the fan away.

**Specifications**

| MODEL NO | RATED VOLTAGE  | RATED POWER |
|----------|----------------|-------------|
| COM-18BK | 220-240V~ 50Hz | 60W         |

**PLEASE FILL YOUR DETAILS FOR FUTURE USE**

| <b>GUARANTEE CARD</b>     |       |
|---------------------------|-------|
| <b>CUSTOMER'S DETAILS</b> |       |
| NAME OF BUYER             | _____ |
| ADDRESS                   | _____ |
| TELEPHONE                 | _____ |
| <b>DETAILS OF SHOP</b>    |       |
| NAME OF SHOP              | _____ |
| RECEIPT VOUCHER NO.       | _____ |
| DATE OF PURCHASE          | _____ |
| <b>APPLIANCE DETAILS</b>  |       |
| TYPE OF APPLIANCE         | _____ |
| MODEL NO.                 | _____ |
| SERIAL NO.                | _____ |