

Instructions:**Mount the remote shutter:**

Open the package, and mount the remote shutter onto the rubber slot of the stick.

Bluetooth pairing:

Turn on your phone's Bluetooth feature, and locate "XMZPG" for pairing. When the flashing stops and turns solid blue, the pairing is completed.

Open the phone holder

Hold the stick with its front facing up, and pull open the phone holder by 90°, and rotate it by 180° to face it towards you.

Fix your phone

Rotate the phone holder to a fit position and extend the rod, then fix your phone on the holder.

Set the tripod

Open the tripod from the bottom, and place it on a even surface.

Functions	
Bluetooth name	XMZPG
Charging	the camera button flashes red to indicate low power and require immediate recharging; During recharging, the red light is on, and then turns blue once fully charged.
Camera	the camera button lights blue to indicate readiness for shooting.
Taking photos	press the camera button.
Turning on for pairing	press and hold the camera button for 2 seconds to turn on the remote shutter for pairing.
Turning off	press and hold the camera button for 3 seconds to turn off the remote shutter.

Functions	
Paired	the camera button lights blue
To be paired	the camera button flashes blue
Sleep mode	the remote shutter enters sleep mode in 10 minutes if it fails to pair, and the light will be dimmed to 20% brightness and cease to flash. It will not turn off during sleep mode.
Exit sleep mode	press the camera button to exit sleep mode and restore 100% brightness. The remote shutter will pair to last connected device as it exits sleep mode, and flash blue if fails to pair.
Connection lost	when your remote shutter loses connection to your phone due to long distance or other reasons, it will enter sleep mode.
Pairing and shooting during charging	the remote shutter works even when it is charging.

Principal: Xiaomi Inc.
 Manufacturer: Beijing Yuemi Technology Co., Ltd
 Address: Room 2057, Building 1, 2 Cui Wei Road, Hai Dian District, Beijing, China

CAUTION
 RISK OF EXPLOSION IF BATTERY IS REPLACED BY AN INCORRECT TYPE.
 DISPOSE OF USED BATTERIES ACCORDING TO THE INSTRUCTIONS

changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with Part 15 of the FCC Rules.

Operation is subject to the following two conditions:
 (1) this device may not cause harmful interference, and
 (2) this device must accept any interference received, including interference that may cause undesired operation